

1/41





FIG. 1

2/41



Checklist Comparison

Standard Approach

- Remove RV Dump Cap
- Connect Sewer Hose to RV
- Connect Hose to Sewer
- Open Black Water Valve
- Flush Black Water Tank
- Close Black Water Tank
- Open Gray Water Tank
- Flush Gray Water Tank
- Close Gray Water Tank
- Disconnect Hose From RV
- Rinse Hose with Fresh Water
- Elevate and Drain Sewer Hose
- Disconnect Hose from Sewer
- Rinse Sewer End of Hose
- Rinse Dump Apron Area
- Stow Sewer Hose
- Place Additive in Black Water Tank via Stool

Invention Approach

- Open Hose Nozzle Hatch
- Pull Hose Nozzle and Place in Sewer
- Release Latch on Hose Nozzle
- Activate Dumping
- Close Latch on Hose Nozzle
- Remove Hose Nozzle from Sewer
- Retract Hose
- Close Hose Nozzle Hatch
- Button Activates Drain Master Additive Injection System Adding Measured Quantity of Tank Additive to Black water and Gray Water Tanks

4/41




FIG. 4

5/41

Hose Nozzle




FIG. 5

6/41




FIG. 6

7/41

Nozzle Compartment




FIG. 7

8/41




FIG. 8

9/41




FIG. 9

10/41

Passenger Side of RV




FIG. 10

11/41

Driver Side of RV




FIG. 11

12/41

Passenger Side of RV





FIG. 12

13/41


Waste Master System Control Panel




1302

Notes:

Service Utilities and Waste Controls switches are master switches
 controlling thrie own group of switch sets



1304



1306

Inside display is a monitor only panel
 Waste Control switches Push once, then again to activate.

Inside Monitor Panel




FIG. 13

14/41




FIG. 14




FIG. 15

16/41




FIG. 16

17/41




FIG. 17

18/41




FIG. 18

19/41




FIG. 19

20/41




FIG. 20

21/41




FIG. 21

22/41




FIG. 22

23/41




FIG. 23

24/41




FIG. 24

25/41




FIG. 25

26/41




FIG. 26

27/41




FIG. 27

28/41




FIG. 28

29/41




FIG. 29




FIG. 30

31/41

WM1 - Waste Master Components

- Hose Nozzle
- Nozzle Box
- Nozzle Box Door (optional)

- Male Fitting - (fits female)
- 25' Sewer Hose (shorter lengths available)
- Female Hose Fitting




FIG. 31

32/41

WM2 - Waste Master Components




FIG. 32

33/41

WM3 - Waste Master Components




FIG. 33

35/41

WM5 - Waste Master Components




FIG. 35

36/41

Wm6 - Waste Master Components




FIG. 36

37/41




FIG. 37

38/41

3800




FIG. 38

39/41

3900




FIG. 39

40/41

4000




FIG. 40

41/41

Service Bay Master

4100




FIG. 41